

TRIPLE S *Customs*

ISUZU TROOPER 1992-2002 VEHICLE WIRING

WIRING INFORMATION: 1992 Isuzu Trooper

WIRE	WIRE COLOR	WIRE LOCATION
12V CONSTANT WIRE	WHITE, WHITE/BLACK	Ignition Harness
STARTER WIRE	WHITE/BLUE	Ignition Harness
IGNITION WIRE	BLACK/YELLOW	Ignition Harness
SECOND IGNITION WIRE	BLACK/RED	Ignition Harness
ACCESSORY WIRE	BLUE	Ignition Harness
POWER DOOR LOCK (-)	GREEN/RED	Harness In Passenger Kick Panel
POWER DOORUNLOCK (-)	GREEN/YELLOW	Harness In Passenger Kick Panel
PARKING LIGHTS (+)	GREEN/RED	Harness Above Fuse Box
DOOR TRIGGER (-)	BLACK/WHITE	In Passenger 'A' Pillar
REAR HATCH TRIGGER (-)	WHITE/BLACK or BLACK/WHITE	At Rear Light
<ul style="list-style-type: none"> If equipped with factory alarm the trunk trigger is GRAY/BLUE at alarm module behind left kick panel. 		
HOOD TRIGGER (-)	RED/WHITE or BROWN/WHITE	At Factory Hood Pin Switch At Factory Alarm Module In Driver's Kick Panel
FACTORY ALARM ARM	ARMS ON LOCK	
FACTORY ALARM DISARM (-)	ORANGE/BLACK	Harness In Driver's Kick Panel
TACHOMETER	BLACK/RED	At Distributor
BRAKE WIRE (+)	GREEN/YELLOW	At Brake Pedal Switch
HORN TRIGGER (-)	BLACK/ORANGE	Harness At Steering Column
LEFT FRONT WINDOW UP	BLUE/WHITE	At Driver Window Motor Inside Door
LEFT FRONT WINDOW DOWN	BLUE	At Driver Window Motor Inside Door
RIGHT FRONT WINDOW UP	RED/YELLOW	At Switch In Driver's Door
RIGHT FRONT WINDOW DOWN	GREEN/YELLOW	At Switch In Driver's Door
LEFT REAR WINDOW UP	RED/BLACK	At Switch In Driver's Door
LEFT REAR WINDOW DOWN	GREEN/BLACK	At Switch In Driver's Door
RIGHT REAR WINDOW UP	RED/BLUE	At Switch In Driver's Door
RIGHT REAR WINDOW DOWN	BROWN	At Switch In Driver's Door

WIRING INFORMATION: 1993 Isuzu Trooper

WIRE	WIRE COLOR	WIRE LOCATION
12V CONSTANT WIRE	WHITE, WHITE/BLACK	Ignition Harness
STARTER WIRE	WHITE/BLUE	Ignition Harness
IGNITION WIRE	BLACK/YELLOW	Ignition Harness
SECOND IGNITION WIRE	BLACK/RED	Ignition Harness
ACCESSORY WIRE	BLUE	Ignition Harness
POWER DOOR LOCK (-)	GREEN/RED	Harness In Passenger Kick Panel
POWER DOORUNLOCK (-)	GREEN/YELLOW	Harness In Passenger Kick Panel
PARKING LIGHTS (+)	GREEN/RED	Harness Above Fuse Box
DOOR TRIGGER (-)	BLACK/WHITE	In Passenger 'A' Pillar
REAR HATCH TRIGGER (-)	WHITE/BLACK or BLACK/WHITE	At Rear Light
<ul style="list-style-type: none"> If equipped with factory alarm the trunk trigger is GRAY/BLUE at alarm module behind left kick panel. 		
HOOD TRIGGER (-)	RED/WHITE or BROWN/WHITE	At Factory Hood Pin Switch At Factory Alarm Module In Driver's Kick Panel
FACTORY ALARM ARM	ARMS ON LOCK	
FACTORY ALARM DISARM (-)	ORANGE/BLACK	Harness In Driver's Kick Panel
TACHOMETER	BLACK/RED	At Distributor
BRAKE WIRE (+)	GREEN/YELLOW	At Brake Pedal Switch
HORN TRIGGER (-)	BLACK/ORANGE	Harness At Steering Column
LEFT FRONT WINDOW UP	BLUE/WHITE	At Driver Window Motor Inside Door
LEFT FRONT WINDOW DOWN	BLUE	At Driver Window Motor Inside Door
RIGHT FRONT WINDOW UP	RED/YELLOW	At Switch In Driver's Door
RIGHT FRONT WINDOW DOWN	GREEN/YELLOW	At Switch In Driver's Door
LEFT REAR WINDOW UP	RED/BLACK	At Switch In Driver's Door
LEFT REAR WINDOW DOWN	GREEN/BLACK	At Switch In Driver's Door
RIGHT REAR WINDOW UP	RED/BLUE	At Switch In Driver's Door
RIGHT REAR WINDOW DOWN	BROWN	At Switch In Driver's Door

WIRING INFORMATION: 1994 Isuzu Trooper

WIRE	WIRE COLOR	WIRE LOCATION
12V CONSTANT WIRE	WHITE, WHITE/BLACK	Ignition Harness
STARTER WIRE	WHITE/BLUE	Ignition Harness
IGNITION WIRE	BLACK/YELLOW	Ignition Harness
SECOND IGNITION WIRE	BLACK/RED	Ignition Harness
ACCESSORY WIRE	BLUE	Ignition Harness
POWER DOOR LOCK (-)	GREEN/RED	Harness In Passenger Kick Panel
POWER DOORUNLOCK (-)	GREEN/YELLOW	Harness In Passenger Kick Panel
PARKING LIGHTS (+)	GREEN/RED	Harness Above Fuse Box
DOOR TRIGGER (-)	BLACK/WHITE	In Passenger 'A' Pillar
REAR HATCH TRIGGER (-)	WHITE/BLACK or BLACK/WHITE	At Rear Light
HOOD TRIGGER (-)	RED/WHITE or BROWN/WHITE	At Factory Hood Pin Switch At Factory Alarm Module In Driver's Kick Panel
FACTORY ALARM ARM	ARMS ON LOCK	
FACTORY ALARM DISARM (-)	ORANGE/BLACK	Harness In Driver's Kick Panel
TACHOMETER	BLACK/RED	At Distributor
BRAKE WIRE (+)	GREEN/YELLOW	At Brake Pedal Switch
HORN TRIGGER (-)	BLACK/ORANGE	Harness At Steering Column
LEFT FRONT WINDOW UP	BLUE/WHITE	At Driver Window Motor Inside Door
LEFT FRONT WINDOW DOWN	BLUE	At Driver Window Motor Inside Door
RIGHT FRONT WINDOW UP	RED/YELLOW	At Switch In Driver's Door
RIGHT FRONT WINDOW DOWN	GREEN/YELLOW	At Switch In Driver's Door
LEFT REAR WINDOW UP	RED/BLACK	At Switch In Driver's Door
LEFT REAR WINDOW DOWN	GREEN/BLACK	At Switch In Driver's Door
RIGHT REAR WINDOW UP	RED/BLUE	At Switch In Driver's Door
RIGHT REAR WINDOW DOWN	BROWN	At Switch In Driver's Door

- If equipped with factory alarm the GRAY/BLUE wire in driver's kick panel gets doors and hatch.
- If equipped with factory alarm the trunk pin is GRAY/BLUE at alarm module behind left kick panel.

WIRING INFORMATION: 1995 Isuzu Trooper

WIRE	WIRE COLOR	WIRE LOCATION
12V CONSTANT WIRE	WHITE, WHITE/BLACK	Ignition Harness
STARTER WIRE	WHITE/BLUE	Ignition Harness
IGNITION WIRE	BLACK/YELLOW	Ignition Harness
SECOND IGNITION WIRE	BLACK/RED	Ignition Harness
ACCESSORY WIRE	BLUE	Ignition Harness
POWER DOOR LOCK (-)	GREEN/RED	Harness In Passenger Kick Panel
POWER DOORUNLOCK (-)	GREEN/BLUE	Harness In Passenger Kick Panel
PARKING LIGHTS (+)	GREEN/RED	Harness Above Fuse Box
DOOR TRIGGER (-)	BLACK/WHITE	In Passenger 'A' Pillar
REAR HATCH TRIGGER (-)	WHITE/BLACK or BLACK/WHITE	At Rear Light
HOOD TRIGGER (-)	RED/WHITE or BROWN/WHITE	At Factory Hood Pin Switch At Factory Alarm Module In Driver's Kick Panel
FACTORY ALARM ARM	ARMS ON LOCK	
FACTORY ALARM DISARM (-)	ORANGE/BLACK	Harness In Driver's Kick Panel
TACHOMETER	BLACK/RED	At Distributor
BRAKE WIRE (+)	GREEN/YELLOW	At Brake Pedal Switch
HORN TRIGGER (-)	BLACK/ORANGE	Harness At Steering Column
LEFT FRONT WINDOW UP	BROWN/WHITE	At Driver Window Motor Inside Door
LEFT FRONT WINDOW DOWN	BLUE	At Driver Window Motor Inside Door
RIGHT FRONT WINDOW UP	BLUE/YELLOW	In Right Front Door
RIGHT FRONT WINDOW DOWN	BROWN/YELLOW	In Right Front Door
LEFT REAR WINDOW UP	BLUE/RED	In Left Rear Door
LEFT REAR WINDOW DOWN	BROWN/RED	In Left Rear Door
RIGHT REAR WINDOW UP	BLUE/RED	In Right Rear Door
RIGHT REAR WINDOW DOWN	BROWN/RED	In Right Rear Door

- If equipped with factory alarm the trunk trigger is GRAY/BLUE at alarm module behind left kick panel.

WIRING INFORMATION: 1996 Isuzu Trooper

WIRE	WIRE COLOR	WIRE LOCATION
12V CONSTANT WIRE	WHITE, WHITE/BLACK	Ignition Harness
STARTER WIRE	BLACK/WHITE	Ignition Harness
IGNITION WIRE	BLACK/YELLOW	Ignition Harness
SECOND IGNITION WIRE	BLACK/RED	Ignition Harness
ACCESSORY WIRE	BLUE	Ignition Harness
POWER DOOR LOCK (-)	LT GREEN/RED	Harness In Drivers Kick Panel
POWER DOOR UNLOCK (-)	BLUE/YELLOW	Harness In Drivers Kick Panel
PARKING LIGHTS (+)	GREEN/RED	Harness Above Fuse Box
DOOR TRIGGER (-)	GREEN/RED	In Passenger 'A' Pillar
DOME SUPERVISION	USE DOOR TRIGGER	
REAR HATCH TRIGGER (-)	BLACK/WHITE	At Rear Light
HOOD TRIGGER (-)	RED/WHITE BROWN/WHITE	At Factory Hood Pin Switch At Factory Alarm Module In Driver's Kick Panel
FACTORY ALARM ARM	ARMS ON LOCK	
FACTORY ALARM DISARM (-)	ORANGE/BLACK	Harness In Driver's Kick Panel Or Factory Alarm Module In Driver's Kick Panel
TACHOMETER WIRE	GREEN or GREEN/STRIPE	Ignition Coil
BRAKE WIRE (+)	GREEN/YELLOW	At Brake Pedal Switch
HORN TRIGGER (-)	BLACK/ORANGE	Harness At Steering Column
LEFT FRONT WINDOW UP	BROWN/WHITE	At Driver Window Motor Inside Door
LEFT FRONT WINDOW DOWN	BLUE	At Driver Window Motor Inside Door
RIGHT FRONT WINDOW UP	BLUE/YELLOW	In Right Front Door
RIGHT FRONT WINDOW DOWN	BROWN/YELLOW	In Right Front Door
LEFT REAR WINDOW UP	BLUE/RED	In Left Rear Door
LEFT REAR WINDOW DOWN	BROWN/RED	In Left Rear Door
RIGHT REAR WINDOW UP	BLUE/RED	In Right Rear Door
RIGHT REAR WINDOW DOWN	BROWN/RED	In Right Rear Door

- If equipped with factory alarm, the GRAY/BLUE wire at the factory alarm module behind left kick panel catches all doors and rear hatch.

WIRING INFORMATION: 1997 Isuzu Trooper

WIRE	WIRE COLOR	WIRE LOCATION
12V CONSTANT WIRE	WHITE, WHITE/BLACK	Ignition Harness
STARTER WIRE	BLACK/WHITE	Ignition Harness
IGNITION WIRE	BLACK/YELLOW	Ignition Harness
SECOND IGNITION WIRE	BLACK/RED	Ignition Harness
ACCESSORY WIRE	BLUE	Ignition Harness
POWER DOOR LOCK (-)	LT GREEN/RED	Harness In Drivers Kick Panel
POWER DOOR UNLOCK (-)	BLUE/YELLOW	Harness In Drivers Kick Panel
PARKING LIGHTS (+)	GREEN/RED	Harness Above Fuse Box
DOOR TRIGGER (-)	GREEN/RED	In Passenger 'A' Pillar
DOME SUPERVISION	USE DOOR TRIGGER	
REAR HATCH TRIGGER (-)	BLACK/WHITE	At Rear Light
HOOD TRIGGER (-)	RED/WHITE BROWN/WHITE	At Factory Hood Pin Switch At Factory Alarm Module In Driver's Kick Panel
FACTORY ALARM ARM	ARMS ON LOCK	
FACTORY ALARM DISARM (-)	ORANGE/BLACK	Harness In Driver's Kick Panel Or Factory Alarm Module In Driver's Kick Panel
TACHOMETER WIRE	GREEN or GREEN/STRIPE	Ignition Coil
BRAKE WIRE (+)	GREEN/YELLOW	At Brake Pedal Switch
HORN TRIGGER (-)	BLACK/ORANGE	Harness At Steering Column
LEFT FRONT WINDOW UP	BROWN/WHITE	At Driver Window Motor Inside Door
LEFT FRONT WINDOW DOWN	BLUE	At Driver Window Motor Inside Door
RIGHT FRONT WINDOW UP	BLUE/YELLOW	In Right Front Door
RIGHT FRONT WINDOW DOWN	BROWN/YELLOW	In Right Front Door
LEFT REAR WINDOW UP	BLUE/RED	In Left Rear Door
LEFT REAR WINDOW DOWN	BROWN/RED	In Left Rear Door
RIGHT REAR WINDOW UP	BLUE/RED	In Right Rear Door
RIGHT REAR WINDOW DOWN	BROWN/RED	In Right Rear Door

- If equipped with factory alarm, the GRAY/BLUE wire at the factory alarm module behind left kick panel catches all doors and rear hatch.

WIRING INFORMATION: 1998 Isuzu Trooper

WIRE	WIRE COLOR	Wire Location
12V CONSTANT WIRE	WHITE/BLACK	Ignition Harness
STARTER WIRE	BLACK/WHITE	Ignition Harness
IGNITION WIRE	BLACK/YELLOW	Ignition Harness
SECOND IGNITION WIRE	BLACK/RED	Ignition Harness
ACCESSORY WIRE	BLUE	Ignition Harness
POWER DOOR LOCK (-)	LT GRN/RED and ORANGE/BLACK	Harness In Driver's Kick Panel Or Factory Security Module Below Radio On Right Side
POWER DOOR UNLOCK (-) **Requires a double pulse**	BLUE/YELLOW and ORANGE/BLACK	Harness In Driver's Kick Panel Or Factory Security Module Below Radio On Right Side
<ul style="list-style-type: none"> The LT. GREEN/RED and BLUE/YELLOW wires are the door key cylinder wires; the ORANGE/BLACK wire is the door key lock/unlock detection wire. Triggering the LT. GREEN/RED and ORANGE/BLACK wires at the same time with a negative will lock the doors and arm the factory security. Triggering the BLUE/YELLOW and ORANGE/BLACK wires at the same time with a negative will unlock the doors and disarm the factory security. 		
PARKING LIGHTS (+)	GREEN/RED	Harness In Driver's Kick Panel
DOOR TRIGGER (-)	GRAY/RED OR GRAY/GREEN	Relay Module Above Passenger's Kick Panel Or Factory Security Module Below Radio On Right Side
DOME SUPERVISION	USE DOOR TRIGGER	
REAR HATCH TRIGGER (-)	RED/YELLOW	Factory Security Module Below Radio On Right Side
HOOD TRIGGER (-)	BROWN/WHITE	Factory Security Module
FACTORY ALARM ARM	ARMS WITH LOCK	
FACTORY ALARM DISARM	DISARMS WITH UNLOCK	
TACHOMETER WIRE	BLACK/RED	At Engine Control Module Under Radio On Left Side
BRAKE WIRE (+)	GREEN/YELLOW	At Brake Pedal Switch
HORN TRIGGER (-)	LT GREEN	Harness Steering Column
LEFT FRONT WINDOW UP	BROWN/WHITE	At Driver Window Motor Inside Door
LEFT FRONT WINDOW DOWN	BLUE	At Driver Window Motor Inside Door
RIGHT FRONT WINDOW UP	BLUE/YELLOW	In Right Front Door
RIGHT FRONT WINDOW DOWN	BROWN/YELLOW	In Right Front Door
LEFT REAR WINDOW UP	BLUE/RED	In Left Rear Door
LEFT REAR WINDOW DOWN	BROWN/RED	In Left Rear Door
RIGHT REAR WINDOW UP	BLUE/RED	In Right Rear Door
RIGHT REAR WINDOW DOWN	BROWN/RED	In Right Rear Door

WIRING INFORMATION: 1999 Isuzu Trooper

WIRE	WIRE COLOR	Wire Location
12V CONSTANT WIRE	WHITE/BLACK	Ignition Harness
STARTER WIRE	BLACK/WHITE	Ignition Harness
IGNITION WIRE	BLACK/YELLOW	Ignition Harness
SECOND IGNITION WIRE	BLACK/RED	Ignition Harness
ACCESSORY WIRE	BLUE	Ignition Harness
POWER DOOR LOCK (-)	LT GRN/RED and ORANGE/BLACK	Harness In Driver's Kick Panel Or Factory Security Module Below Radio On Right Side
POWER DOOR UNLOCK (-) **Requires a double pulse**	BLUE/YELLOW and ORANGE/BLACK	Harness In Driver's Kick Panel Or Factory Security Module Below Radio On Right Side
<ul style="list-style-type: none"> The LT. GREEN/RED and BLUE/YELLOW wires are the door key cylinder wires; the ORANGE/BLACK wire is the door key lock/unlock detection wire. Triggering the LT. GREEN/RED and ORANGE/BLACK wires at the same time with a negative will lock the doors and arm the factory security. Triggering the BLUE/YELLOW and ORANGE/BLACK wires at the same time with a negative will unlock the doors and disarm the factory security. 		
PARKING LIGHTS (+)	GREEN/RED	Harness In Driver's Kick Panel
DOOR TRIGGER (-)	GRAY/RED OR GRAY/GREEN	Relay Module Above Passenger's Kick Panel Or Factory Security Module Below Radio On Right Side
DOME SUPERVISION	USE DOOR TRIGGER	
REAR HATCH TRIGGER (-)	RED/YELLOW	Factory Security Module Below Radio On Right Side
HOOD TRIGGER (-)	BROWN/WHITE	Factory Security Module Below Radio On Right Side
FACTORY ALARM ARM	ARMS WITH LOCK	
FACTORY ALARM DISARM	DISARMS WITH UNLOCK	
TACHOMETER WIRE	BLACK/RED	At Engine Control Module Under Radio On Left Side
BRAKE WIRE (+)	GREEN/YELLOW	At Brake Pedal Switch
HORN TRIGGER (-)	LT GREEN	Harness Steering Column
LEFT FRONT WINDOW UP	BROWN/WHITE	At Driver Window Motor Inside Door
LEFT FRONT WINDOW DOWN	BLUE	At Driver Window Motor Inside Door
RIGHT FRONT WINDOW UP	BLUE/YELLOW	In Right Front Door
RIGHT FRONT WINDOW DOWN	BROWN/YELLOW	In Right Front Door
LEFT REAR WINDOW UP	BLUE/RED	In Left Rear Door
LEFT REAR WINDOW DOWN	BROWN/RED	In Left Rear Door
RIGHT REAR WINDOW UP	BLUE/RED	In Right Rear Door
RIGHT REAR WINDOW DOWN	BROWN/RED	In Right Rear Door

WIRING INFORMATION: 2000 Isuzu Trooper

WIRE	WIRE COLOR	Wire Location
12V CONSTANT WIRE	WHITE/BLACK	Ignition Harness
STARTER WIRE	BLACK/WHITE	Ignition Harness
IGNITION WIRE	BLACK/YELLOW	Ignition Harness
SECOND IGNITION WIRE	BLACK/RED	Ignition Harness
ACCESSORY WIRE	BLUE	Ignition Harness
POWER DOOR LOCK (-)	LT GRN/RED and ORANGE/BLACK	Harness In Driver's Kick Panel Or Factory Security Module Below Radio On Right Side
POWER DOOR UNLOCK (-) **Requires a double pulse**	BLUE/YELLOW and ORANGE/BLACK	Harness In Driver's Kick Panel Or Factory Security Module Below Radio On Right Side
<ul style="list-style-type: none"> The LT. GREEN/RED and BLUE/YELLOW wires are the door key cylinder wires; the ORANGE/BLACK wire is the door key lock/unlock detection wire. Triggering the LT. GREEN/RED and ORANGE/BLACK wires at the same time with a negative will lock the doors and arm the factory security. Triggering the BLUE/YELLOW and ORANGE/BLACK wires at the same time with a negative will unlock the doors and disarm the factory security. 		
PARKING LIGHTS (+)	GREEN/RED	Harness In Passenger's Kick Panel
DOOR TRIGGER (-)	GRAY/RED OR GRAY/GREEN	Relay Module Above Passenger's Kick Panel Or Factory Security Module Below Radio On Right Side
DOME SUPERVISION	USE DOOR TRIGGER	
REAR HATCH TRIGGER (-)	RED/YELLOW	Factory Security Module Below Radio On Right Side
HOOD TRIGGER (-)	BROWN/WHITE	Factory Security Module Below Radio On Right Side
FACTORY ALARM ARM	ARMS WITH LOCK	
FACTORY ALARM DISARM	DISARMS WITH UNLOCK	
TACHOMETER WIRE	BLACK/RED	At Engine Control Module Under Radio On Left Side
BRAKE WIRE (+)	GREEN/YELLOW	At Brake Pedal Switch
HORN TRIGGER (-)	LT GREEN	Harness Steering Column
LEFT FRONT WINDOW UP	BROWN/WHITE	At Driver Window Motor Inside Door
LEFT FRONT WINDOW DOWN	BLUE	At Driver Window Motor Inside Door
RIGHT FRONT WINDOW UP	BLUE/YELLOW	In Right Front Door
RIGHT FRONT WINDOW DOWN	BROWN/YELLOW	In Right Front Door
LEFT REAR WINDOW UP	BLUE/RED	In Left Rear Door
LEFT REAR WINDOW DOWN	BROWN/RED	In Left Rear Door
RIGHT REAR WINDOW UP	BLUE/RED	In Right Rear Door
RIGHT REAR WINDOW DOWN	BROWN/RED	In Right Rear Door

WIRING INFORMATION: 2001 Isuzu Trooper

WIRE	WIRE COLOR	Wire Location
12V CONSTANT WIRE	WHITE/BLACK	Ignition Harness
STARTER WIRE	BLACK/WHITE	Ignition Harness
IGNITION WIRE	BLACK/YELLOW	Ignition Harness
SECOND IGNITION WIRE	BLACK/RED	Ignition Harness
ACCESSORY WIRE	BLUE	Ignition Harness
POWER DOOR LOCK (-)	LT GRN/RED and ORANGE/BLACK	Harness In Driver's Kick Panel Or Factory Security Module Below Radio On Right Side
POWER DOOR UNLOCK (-) **Requires a double pulse**	BLUE/YELLOW and ORANGE/BLACK	Harness In Driver's Kick Panel Or Factory Security Module Below Radio On Right Side
<ul style="list-style-type: none"> The LT. GREEN/RED and BLUE/YELLOW wires are the door key cylinder wires; the ORANGE/BLACK wire is the door key lock/unlock detection wire. Triggering the LT. GREEN/RED and ORANGE/BLACK wires at the same time with a negative will lock the doors and arm the factory security. Triggering the BLUE/YELLOW and ORANGE/BLACK wires at the same time with a negative will unlock the doors and disarm the factory security. 		
PARKING LIGHTS (+)	GREEN/RED	Harness In Passenger's Kick Panel
DOOR TRIGGER (-)	GRAY/RED OR GRAY/GREEN	Relay Module Above Passenger's Kick Panel Or Factory Security Module Below Radio On Right Side
DOME SUPERVISION	USE DOOR TRIGGER	
REAR HATCH TRIGGER (-)	RED/YELLOW	Factory Security Module Below Radio On Right Side
HOOD TRIGGER (-)	BROWN/WHITE	Factory Security Module
FACTORY ALARM ARM	ARMS WITH LOCK	
FACTORY ALARM DISARM	DISARMS WITH UNLOCK	
TACHOMETER WIRE	BLACK/RED	At Engine Control Module Under Radio On Left Side
BRAKE WIRE (+)	GREEN/YELLOW	At Brake Pedal Switch
HORN TRIGGER (-)	LT GREEN	Harness Steering Column
LEFT FRONT WINDOW UP	BROWN/WHITE	At Driver Window Motor Inside Door
LEFT FRONT WINDOW DOWN	BLUE	At Driver Window Motor Inside Door
RIGHT FRONT WINDOW UP	BLUE/YELLOW	In Right Front Door
RIGHT FRONT WINDOW DOWN	BROWN/YELLOW	In Right Front Door
LEFT REAR WINDOW UP	BLUE/RED	In Left Rear Door
LEFT REAR WINDOW DOWN	BROWN/RED	In Left Rear Door
RIGHT REAR WINDOW UP	BLUE/RED	In Right Rear Door
RIGHT REAR WINDOW DOWN	BROWN/RED	In Right Rear Door

WIRING INFORMATION: 2002 Isuzu Trooper

WIRE	WIRE COLOR	Wire Location
12V CONSTANT WIRE	WHITE/BLACK	Ignition Harness
STARTER WIRE	BLACK/WHITE	Ignition Harness
IGNITION WIRE	BLACK/YELLOW	Ignition Harness
SECOND IGNITION WIRE	BLACK/RED	Ignition Harness
ACCESSORY WIRE	BLUE	Ignition Harness
POWER DOOR LOCK (-)	LT GRN/RED and ORANGE/BLACK	Harness In Driver's Kick Panel Or Factory Security Module Below Radio On Right Side
POWER DOOR UNLOCK (-) **Requires a double pulse**	BLUE/YELLOW and ORANGE/BLACK	Harness In Driver's Kick Panel Or Factory Security Module Below Radio On Right Side
<ul style="list-style-type: none"> The LT. GREEN/RED and BLUE/YELLOW wires are the door key cylinder wires; the ORANGE/BLACK wire is the door key lock/unlock detection wire. Triggering the LT. GREEN/RED and ORANGE/BLACK wires at the same time with a negative will lock the doors and arm the factory security. Triggering the BLUE/YELLOW and ORANGE/BLACK wires at the same time with a negative will unlock the doors and disarm the factory security. 		
PARKING LIGHTS (+)	GREEN/RED	Harness In Passenger's Kick Panel
DOOR TRIGGER (-)	GRAY/RED OR GRAY/GREEN	Relay Module Above Passenger's Kick Panel Or Factory Security Module Below Radio On Right Side
DOME SUPERVISION	USE DOOR TRIGGER	
REAR HATCH TRIGGER (-)	RED/YELLOW	Factory Security Module Below Radio On Right Side
HOOD TRIGGER (-)	BROWN/WHITE	Factory Security Module Below Radio On Right Side
FACTORY ALARM ARM	ARMS WITH LOCK	
FACTORY ALARM DISARM	DISARMS WITH UNLOCK	
TACHOMETER WIRE	BLACK/RED	At Engine Control Module Under Radio On Left Side
BRAKE WIRE (+)	GREEN/YELLOW	At Brake Pedal Switch
HORN TRIGGER (-)	LT GREEN	Harness Steering Column
LEFT FRONT WINDOW UP	BROWN/WHITE	At Driver Window Motor Inside Door
LEFT FRONT WINDOW DOWN	BLUE	At Driver Window Motor Inside Door
RIGHT FRONT WINDOW UP	BLUE/YELLOW	In Right Front Door
RIGHT FRONT WINDOW DOWN	BROWN/YELLOW	In Right Front Door
LEFT REAR WINDOW UP	BLUE/RED	In Left Rear Door
LEFT REAR WINDOW DOWN	BROWN/RED	In Left Rear Door
RIGHT REAR WINDOW UP	BLUE/RED	In Right Rear Door
RIGHT REAR WINDOW DOWN	BROWN/RED	In Right Rear Door